

WALK IN HINGE SELECTOR CHART

HOW TO USE THE HINGE SELECTOR CHART

1. Locate the weight of your door in the far left column, headed door weight.
2. Find the width of your door along the bottom of the chart.
3. Where the weight line and width column intersect, find the recommended hinge group code (A, B, etc).
4. Select your hinges from the hinge groups below.

NOTE: If exact dimensions and weight for your door is not shown, use the next higher width and weight.

Hinge groups A-C shown in REACH-IN Section

Hinge groups D-J shown in WALK-IN Section

LOAD CHART

DOOR WEIGHTS																					
kg.	lb.																				
226.8	500	D	D	E	F	F	F	G	G	G	G	H	H	H	H	H	H	J	J	J	J
217.7	480	D	D	E	F	F	F	G	G	G	G	H	H	H	H	H	H	J	J	J	J
208.6	460	D	D	E	F	F	F	G	G	G	G	H	H	H	H	H	H	H	J	J	J
199.5	440	D	D	D	E	F	F	F	G	G	G	G	H	H	H	H	H	H	J	J	J
190.5	420	D	D	D	E	F	F	F	G	G	G	G	H	H	H	H	H	H	H	H	J
181.4	400	D	D	D	E	E	F	F	F	G	G	G	G	H	H	H	H	H	H	H	H
172.4	380	D	D	D	D	E	F	F	F	G	G	G	G	G	H	H	H	H	H	H	H
163.3	360	D	D	D	D	E	E	F	F	F	G	G	G	G	G	H	H	H	H	H	H
154.2	340	D	D	D	D	E	E	F	F	F	F	G	G	G	G	G	H	H	H	H	H
145.2	320	C	D	D	D	D	E	E	F	F	F	F	G	G	G	G	G	H	H	H	H
136.1	300	C	D	D	D	D	E	E	E	F	F	F	F	G	G	G	G	G	G	H	H
127.0	280	C	D	D	D	D	E	E	F	F	F	F	F	G	G	G	G	G	G	G	H
117.9	260	C	C	D	D	D	D	E	E	F	F	F	F	F	G	G	G	G	G	G	G
108.9	240	C	C	D	D	D	D	D	E	E	F	F	F	F	F	F	G	G	G	G	G
99.8	220	C	C	C	D	D	D	D	D	E	E	E	F	F	F	F	F	F	G	G	G
90.7	200	B	C	C	D	D	D	D	D	D	E	E	E	F	F	F	F	F	F	F	G
81.7	180	B	C	C	C	D	D	D	D	D	D	E	E	E	E	F	F	F	F	F	F
72.6	160	B	B	C	C	C	D	D	D	D	D	D	D	E	E	E	E	F	F	F	F
63.5	140	B	B	C	C	C	C	D	D	D	D	D	D	D	D	D	E	E	E	E	F
54.4	120	B	B	B	C	C	C	C	C	D	D	D	D	D	D	D	D	D	E	E	E
45.4	100	A	B	B	B	B	C	C	C	C	C	D	D	D	D	D	D	D	D	D	D
36.3	80	A	A	B	B	B	B	C	C	C	C	C	C	D	D	D	D	D	D	D	D
27.2	60	A	A	A	A	B	B	B	B	B	B	C	C	C	C	C	C	C	C	D	D
18.1	40	A	A	A	A	A	A	A	A	B	B	B	B	B	B	B	B	B	C	C	C
9.0	20	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	B
DOOR WIDTH	in.	12	15	18	21	24	27	30	33	36	39	42	45	48	51	54	57	60	63	66	69
	cm.	30.5	38.1	45.7	53.3	61.0	68.6	76.2	83.8	91.4	99.1	106.7	114.3	121.9	129.5	137.2	144.8	152.4	160.0	167.6	175.3

HINGE GROUPS

GROUP	HINGE SERIES NUMBERS
A	139, 211, 212, 213, 214, 215, 225, 1070, 1216, 1216-13, 1219
B	217, 217S, 218, 220, 1070A, 1071, 1220, 1510, 1511, 1512, 1513, 1521, 1522, 1530, 1531, 1532, 1533, 1556
C	1061, 1071A, 1247, 1257, 1263, 1267, 1268, 1269, 1367R, 1550
D	1241, 1243, 1245, 1246, 1248, 1249, 1251, 1255, 1256, 1341
E	1035, 1074
F	1037, 1055, 1214, 1240, 1409
G	998, 1073, 12, 77, 1277L, 1277S, 1277T, 1398
H	1075, 1076, 1275, 1276
J	94